

#### CAUTION

- Use only water with a neutral pH (7).
- Do not expose to direct sun light for extended periods of time.
- Do not expose to excessive cold or heat (40° F min to 113° F max).
- Use a check valve as required to prevent back-flow.
- Maximum pressure of 116 psi, use a pressure reducer as required.
- Use an anti-hammering device as required.
- Insure breather valve is closed (including after filter replacement).

#### INSTALLATION:

**IMPORTANT NOTE:** For best performance, water pressure to the steam generator should be 15 to 20 psig.

- All plumbing shall be done in accordance with local and national plumbing codes.
- Turn-off water supply before installation or service.
- Use the supplied wall bracket to prevent excessive loading on the steam generator.
- Connect the supply plumbing to the side marked with the "IN arrow" and the outlet plumbing to the side with the "OUT arrow".

#### CAUTION

Do not over tighten the threaded connections on the filter.

- Use only Teflon tape as a sealant for the connections.
- The installation of a By-pass is recommended.
- After the installation, let the water flow through the filter for at least 5 minutes before using, check for leaks.

#### MAINTENANCE:



- Filter change recommended every 6 months
- When replacing the filter, clean the filter cup with cold water and a soft sponge.
- Before opening to replace filter: turn-off the water mains and release the pressure from the product by un-screwing the breathe-valve (located on top of filter), be sure to close afterwards. Only use the wrench provided when replacing the filter cartridge.
- If not in use for a long time, remove cartridge to remove stagnant water. Before using again clean filter cup and use a new cartridge.
- After maintenance, let the water flow for at least 5 minutes before using.

#### WARNING

Only replace cartridge with Mr.Steam part number MS-CARTRIDGE. Using other cartridges will void the warranty and may cause property damage.

#### BOX CONTENTS:

- Filter Casing
- Filter Cartridge
- Mounting Bracket
- Wrench
- Instructions



All drawings are for illustrative purposes only



**Warranty:** To view or download the Mr. Steam® warranty and register your product go to: [blog.mrsteam.com/wr](http://blog.mrsteam.com/wr)