

Model MS Super4E

Serial Number 9000000 and higher
MS Super 4E includes (2) MS Super 1E units

Mr.Steam Standard Features

- Stainless steel tank
- Industrial, large diameter, serviceable heating element
- Modular Plug and Play connections
- Electronic water-level-control system
- Full-port drain valve.
- Limited lifetime steam generator parts warranty

Safety Features

- Built-in, low-voltage 24-volt control
- ASME safety valve


- 60-minute electronic countdown shutdown with 75-minute limiting safety back-up

Locating and Installing the Steam Generator Unit

- Select a location as near as practical to the steam room, within 60 feet. Typical locations include: closet, vanity cabinet, heated attic or basement
- Do not install steambath generator inside the steam room.
- Do not install steambath generator outdoors or wherever environmental conditions may affect the safety and/or performance of the generator
- Do not install steambath generator or plumbing lines in unheated attic or any locations where water could freeze
- Do not install steambath generator near flammable or corrosive materials
- or chemicals or in areas having a high concentration of chlorine
- Install steambath generator on a solid and level surface or securely mounted to a wall using the keyhole slots provided.
- Install steambath generator in an upright position only
- Provide a minimum of 12 inches inches at both ends and top of the steam generator or as required for servicing. Alternately provide unions to facilitate installation and disconnection of the steam generator.
- The minimum clearance from combustible surfaces is zero all around.

Required Plumbing

Steam Outlet (1/2" NPT) Safety Valve (3/4" NPT) Drain (1/2" NPT)
Steam Head (1/2" NPT) Water Supply (3/8" NPT)



Electrical

All electrical wiring to be installed by a qualified licensed electrician in accordance with National Electrical Code and local electrical code.

Power Wiring

1. Check power voltage. Use 240V rated unit when supply matches rating of unit before installation.
2. Use minimum 90° C/300V rated insulated copper conductors only, type THHN or equal sized in accordance with National Electrical Code and local electrical code for the Amps in Ampere Chart. If allowed by code, NM cable may require a larger wire size than as listed on the chart.
3. Connect suitably sized equipment grounding wire to ground terminal provided.
4. Install a separate circuit breaker between supply and unit. Provide a power supply disconnect within sight of the steam generator or one that is capable of being locked in the open position.

AMPERE CHART

| MODEL NO. | MAX ROOM VOL. CU.FT. | KW | VOLTS 1 PH | TOTAL REQUIRED AMPS | WIRE SIZE (AWG) |
|-------------|----------------------|----|------------|---------------------|-----------------|
| MS Super4E* | 875 | 20 | 208 | 2 x 49=98 amps | 6 |
| | | | 240 | 2 x 42=84 amps | 8 |

FOR ILLUSTRATIVE PURPOSES ONLY. IMPORTANT NOTE: FOR SAFE AND TROUBLE FREE INSTALLATION visit mrsteam.com or scan the QR code before installation to download the Installation, Operation and Maintenance Manual or refer to the manual provided with the unit.



*MS Super 4E includes (2) MS Super 1E units

| MODEL | VOLTAGE* | PHASE | OPTIONS | PROJECT INFORMATION | |
|-----------|---------------------------------------|---|--|---------------------|---------------|
| MSSuper4E | <input type="checkbox"/> B=208 | <input type="checkbox"/> 1-Single Phase | <input type="checkbox"/> Express Steam | Location: | Contractor: |
| | <input type="checkbox"/> C=240 | <input type="checkbox"/> 3-Three Phase | | Architect: | Submitted By: |
| | *Contact Mr. Steam for other voltages | | | Engineer: | Date: |
| Notes: | | | | | |

Required Equipment: iSteam, or iSteamPlus Control

Optional Equipment: iGenie, AudioWizard, ChromaSteam, HomeWizard, Recessed Light, MS Light, MS Wallseat, AutoFlush, Drip Pan, AromaSteam, Chlorine Filter, FORM Shower Systems



Model MS Super5E

Serial Number 9000000 and higher
MS Super 5E includes (2) MS Super 2E units

Mr.Steam Standard Features

- Stainless steel tank
- Industrial, large diameter, serviceable heating element
- Modular Plug and Play connections
- Electronic water-level-control system
- Full-port drain valve.
- Limited lifetime steam generator parts warranty

Safety Features


- Built-in, low-voltage 24-volt control
- ASME safety valve
- 60-minute electronic countdown shutdown with 75-minute limiting safety back-up

Locating and Installing the Steam Generator Unit

- Select a location as near as practical to the steam room, within 60 feet. Typical locations include: closet, vanity cabinet, heated attic or basement
- Do not install steambath generator inside the steam room.
- Do not install steambath generator outdoors or wherever environmental conditions may affect the safety and/or performance of the generator
- Do not install steambath generator or plumbing lines in unheated attic or any locations where water could freeze
- Do not install steambath generator near flammable or corrosive materials
- or chemicals or in areas having a high concentration of chlorine
- Install steambath generator on a solid and level surface or securely mounted to a wall using the keyhole slots provided.
- Install steambath generator in an upright position only
- Provide a minimum of 12 inches inches at both ends and top of the steam generator or as required for servicing. Alternately provide unions to facilitate installation and disconnection of the steam generator.
- The minimum clearance from combustible surfaces is zero all around.

Required Plumbing

Steam Outlet (1/2" NPT) Safety Valve (3/4" NPT) Drain (1/2" NPT)
Steam Head (1/2" NPT) Water Supply (3/8" NPT)



Electrical

All electrical wiring to be installed by a qualified licensed electrician in accordance with National Electrical Code and local electrical code.

Power Wiring

1. Check power voltage. Use 240V rated unit when supply matches rating of unit before installation.
2. Use minimum 90° C/300V rated insulated copper conductors only, type THHN or equal sized in accordance with National Electrical Code and local electrical code for the Amps in Ampere Chart. If allowed by code, NM cable may require a larger wire size than as listed on the chart.
3. Connect suitably sized equipment grounding wire to ground terminal provided.
4. Install a separate circuit breaker between supply and unit. Provide a power supply disconnect within sight of the steam generator or one that is capable of being locked in the open position.

AMPERE CHART

| MODEL NO. | MAX ROOM VOL. CU.FT. | KW | VOLTS 1 PH | TOTAL REQUIRED AMPS | WIRE SIZE (AWG) |
|-------------|----------------------|----|------------|---------------------|-----------------|
| MS Super5E* | 1075 | 24 | 208 | 2x58=116 amps | 6 |
| | | | 240 | 2x50= 100 amps | 6 |

FOR ILLUSTRATIVE PURPOSES ONLY. IMPORTANT NOTE: FOR SAFE AND TROUBLE FREE INSTALLATION visit mrsteam.com or scan the QR code before installation to download the Installation, Operation and Maintenance Manual or refer to the manual provided with the unit.



*MS Super 5E includes (2) MS Super 2E units

| MODEL | VOLTAGE* | PHASE | OPTIONS | PROJECT INFORMATION | |
|---------------------------------------|--------------------------------|---|--|---------------------|---------------|
| MSSuper5E | <input type="checkbox"/> B=208 | <input type="checkbox"/> 1-Single Phase | <input type="checkbox"/> Express Steam | Location: | Contractor: |
| | <input type="checkbox"/> C=240 | <input type="checkbox"/> 3-Three Phase | | Architect: | Submitted By: |
| *Contact Mr. Steam for other voltages | | | | Engineer: | Date: |
| Notes: | | | | | |

Required Equipment: iSteam, or iSteamPlus Control

Optional Equipment: iGenie, AudioWizard, ChromaSteam, HomeWizard, Recessed Light, MS Light, MS Wallseat, AutoFlush, Drip Pan, AromaSteam, Chlorine Filter, FORM Shower Systems



Model MS Super6E

Serial Number 9000000 and higher
MS Super 6E includes (2) MS Super 3E units

Mr.Steam Standard Features

- Stainless steel tank
- Industrial, large diameter, serviceable heating element
- Modular Plug and Play connections
- Electronic water-level control system
- Full-port drain valve.
- Limited lifetime steam generator parts warranty

Safety Features


- Built-in, low-voltage 24-volt control
- ASME safety valve
- 60-minute electronic countdown shutdown with 75-minute limiting safety back-up

Locating and Installing the Steam Generator Unit

- Select a location as near as practical to the steam room, within 60 feet. Typical locations include: closet, vanity cabinet, heated attic or basement
- Do not install steambath generator inside the steam room.
- Do not install steambath generator outdoors or wherever environmental conditions may affect the safety and/or performance of the generator
- Do not install steambath generator or plumbing lines in unheated attic or any locations where water could freeze
- Do not install steambath generator near flammable or corrosive materials
- or chemicals or in areas having a high concentration of chlorine
- Install steambath generator on a solid and level surface or securely mounted to a wall using the keyhole slots provided.
- Install steambath generator in an upright position only
- Provide a minimum of 12 inches inches at both ends and top of the steam generator or as required for servicing. Alternately provide unions to facilitate installation and disconnection of the steam generator.
- The minimum clearance from combustible surfaces is zero all around.

Required Plumbing

Steam Outlet (1/2" NPT) Safety Valve (3/4" NPT) Drain (1/2" NPT)
Steam Head (1/2" NPT) Water Supply (3/8" NPT)



Electrical

All electrical wiring to be installed by a qualified licensed electrician in accordance with National Electrical Code and local electrical code.

Power Wiring

1. Check power voltage. Use 240V rated unit when supply matches rating of unit before installation.
2. Use minimum 90° C/300V rated insulated copper conductors only, type THHN or equal sized in accordance with National Electrical Code and local electrical code for the Amps in Ampere Chart. If allowed by code, NM cable may require a larger wire size than as listed on the chart.
3. Connect suitably sized equipment grounding wire to ground terminal provided.
4. Install a separate circuit breaker between supply and unit. Provide a power supply disconnect within sight of the steam generator or one that is capable of being locked in the open position.

AMPERE CHART

| MODEL NO. | MAX ROOM VOL. CU.FT. | KW | VOLTS 1 PH | TOTAL REQUIRED AMPS | WIRE SIZE (AWG) |
|-------------|----------------------|----|------------|---------------------|-----------------|
| MS Super6E* | 1275 | 30 | 208 | 2 x 73= 146 amps | 4 |
| | | | 240 | 2 x 63= 126 amps | 4 |

FOR ILLUSTRATIVE PURPOSES ONLY. IMPORTANT NOTE: FOR SAFE AND TROUBLE FREE INSTALLATION visit mrsteam.com or scan the QR code before installation to download the Installation, Operation and Maintenance Manual or refer to the manual provided with the unit.



*MS Super 6E includes (2) MS Super 3E units

| MODEL | VOLTAGE* | PHASE | OPTIONS | PROJECT INFORMATION | |
|-----------|---------------------------------------|---|--|---------------------|---------------|
| MSSuper6E | <input type="checkbox"/> B=208 | <input type="checkbox"/> 1-Single Phase | <input type="checkbox"/> Express Steam | Location: | Contractor: |
| | <input type="checkbox"/> C=240 | <input type="checkbox"/> 3-Three Phase | | Architect: | Submitted By: |
| | *Contact Mr. Steam for other voltages | | | Engineer: | Date: |
| Notes: | | | | | |

Required Equipment: iSteam, or iTempPlus Control

Optional Equipment: iGenie, AudioWizard, ChromaSteam, HomeWizard, Recessed Light, MS Light, MS Wallseat, AutoFlush, Drip Pan, AromaSteam, Chlorine Filter, FORM Shower Systems

