




mr.steam®

THE INTELLIGENT STEAMBATH

All generators work with all steam controls and the new SteamLinX App

- Built with corrosion resistant and recyclable stainless steel
- Can be installed up to 60 feet from the shower
- Plug and Play components for easy installation
- AutoSteam® standard with every generator for even flow of steam
- Precision temperature probe for optimal steam room temperature controls
- Limited Lifetime Warranty
- All MS generators available in 240v/1 Ph use C1 suffix. For 208v/1Ph generators use B1 suffix. For all other voltages and phases please contact us

Product Dimensions*	Model No.	Total Room Volume (cu.ft.)	kW	Amps 240/1PH	Wire Size AWG‡	Water Usage Gallons††	Shipping Wt.(lbs.)**	List Price
 MS Generators 14 1/2" x 14 3/4" x 6 3/4"	MS90E	up to 100	5	21	10	0.67	27	\$1,950
	MS150E	101-150	6	25	8	0.80	27	\$2,450
	MS225E	151-225	7.5	32	8	1.0	27	\$2,700
	MS400E	226-360	9	38	8	1.2	27	\$2,900
 SUPER Generators 17" x 18 1/2" x 7 7/8"	MSSUPERIE	361-475	10	42	8	1.4	39	\$3,350
	MSSUPER2E	476-575	12	50	6	1.6	39	\$3,750
	MSSUPER3E	576-675	15	63	4	2.0	39	\$4,250
NEW  MAX Generators 27 5/8" x 20 3/4" x 7 7/8"	MX4E	676-875	20	84	2	2.7	67	\$5,300
	MX5E	876-1075	24	100	1	3.2	67	\$5,600
	MX6E	1076-1275	30	125	2/0	4.0	67	\$5,900

Get instant sizing help. Go to virtualspa.mrsteam.com

Call for assistance with technical specifications 800-767-8326 , or visit mrsteam.com

1. Measure length, width and height of the steam enclosure (in feet):

Multiply the Length ___ x Width ___ x Height ___

ROOM VOLUME =

2. Construction Materials:

- For natural stones: natural marble, stone, shale, glass block or concrete.

Add 110%

- For ceramic, porcelain, or glass tile on cement board or mortar bed.

Add 40%

- For ceilings above 8 ft, add (15% per foot, max 10 feet).

Add 15%

3. Add all figures to obtain the Total Adjusted Volume required.

TAV

Compare your TOTAL ADJUSTED ROOM VOLUME to the Specification Chart for Residential and select the appropriate generator model

Occasionally a steam room has unforeseeable or hidden construction that warrants special sizing or other consideration. MrSteam is not responsible if unconventional and/or unforeseeable materials or construction details result in a unit that does not operate to specification. Refer to the applicable MrSteam Installation, Operation & Maintenance Manual, available at mrsteam.com, and consult a properly licensed contractor, architect, and/or design professional. Failure to do so may result in inoperable or hazardous conditions.

‡ Wire size (AWG) based on minimum 90 °C rated THHN copper conductors. Refer to the National Electrical Code for other types of conductors.

* Dimensions are for generator only, without AutoFlush® or plumbing features.

** Shipping weight is for generator only, without control or SteamHead.

†† Water usage based on 20 minutes of operation.